


Megapixel AHD Car Camera User Manual



Before you use this product, please read the introduction

1. Main Parts & Accessories



Main Part(1PCS)




Assorted screw




User Manual
(1PCS)

2. Connection Diagram




3. 4P Aviation Plug Connector

Video Output: Aviation Plug Connector



Aviation RS765-4(Female)
1---12VDC(+) 3---AUDIO
2---12GND(-) 4---VIDEO



5. Notes

- (1) Make sure the power is off before installation.
- (2) Check and confirm the availability of right power supply. Wrong voltage will inflict damage to component(s) in camera.
- (3) Do not use camera in overheated and humid environment. Keep a good ventilation so as to reduce fire and outage.
- (4) Only the professional technicians are entitled for installation and repair. By no means, this camera shall not be repaired or dismantled on customer's own. Manufacturer holds no responsibility in case of unauthorized repair, and use of uncertified spare parts.
- (5) If abnormal conditions are found, please turn off the power supply and contact the local dealers in time.

Image sensor	CMOS	Starlight CMOS
Horizontal Resolution	1.3Megapixel	1.3Megapixel
TV system	PAL/NTSC	PAL/NTSC
Effective Pixel	1280(H)*960(V)	1280(H)*960(V)
Minimum Illumination	Color 0.1Lux , 0 Lux with IR	Color 0.01Lux , 0 Lux with IR
S/N ratio	≥45dB	≥60dB
Day/Night mode	Color to Blackwhite switch automatically	
sync system	Internal	
Backlight compensation	AUTO	
White balance	AUTO	
Electronic shutter	AUTO/1/50 (1/60) -1 (50 , 000Sec)	
Video output	AHD(default)Standard , 720P output	
lens	2.8mm	
IR leds Qty	7pcs LEDs	
IR distance	≤5 meters	
waterproof grade	IP67	
Operating Temp.	-20°C~+70°C	
Power supply	DC12V±10%	

The contents of this manual are for reference only